








197-000175



Instruction Manual





A01 20x *14 mm	A02 20x *5x45 mm	A03 23x *8x30 mm	A04 20x *14 mm
A10 16x *3.5x18 mm	A12 4x 	A13 4x 	A14 15x *4x25 mm
A15 5x 	A16 4x *3.5x50 mm	A17 2x *5x70 mm	A18 2x
A19 2x 	A20 2x 	A28 12x 	A41 4x






Important information
Read carefully.
Keep this information for further reference.

GB WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.


8.






1.






2.




3.




4.



6.



8.



2x