













197-000193



Instruction Manual





A01 29x  *14 mm	A02 29x  *5x45 mm	A03 42x  *8x30 mm	A04 29x 
A10 16x  3*5x18 mm			








Important information
 Read carefully.
 Keep this information for further reference.



(GB) WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.



Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.





4.




5.



6.



7.



8.

