











Instalation manual

Juliet Bed 160




Element symbol	Dimensions				Code	Package
1	950	150	22	1	j-109	2/3
2	950	150	22	1	j-110	2/3
3	284	150	22	1	j-111	2/3
4	284	150	22	1	j-112	2/3
5	200	2000	22	1	j-113	2/3
6	200	2000	22	1	j-113	2/3
7	100	1670	22	1	j-408	2/3
8	100	1670	22	1	j-409	2/3
9	840	1368	16	1	J-006	1/3
10	156	1368	16	1	J-007	2/3
11			25	2		
12			27	1		
13			27	1		
14			20	2		


4x n221	16x φ3,5x16 mm p25				
32x 6 x13 mm e2	12x φ4x45 mm p11	12x φ4x35 mm p6	6x φ3,5x25 mm p16	2x e1	2x s1
2x n34	2x n34	24x φ15x120mm #16 r1	12x r10	1x 50g	10x 46x184 mm f11
1x z1	32x f8x30 mm f1	24x φ16 s2	8x φ6x13 mm e3	4x 115x115x122 mm n106	8x k1




1




3







2




4



5**6****7****8**

9



10

