















# Instalation manual

ALEX: Chest




Element symbol	Dimensions				Code	Package
1	838	354	16	1	A - 101	1/1
2	838	354	16	1	A - 102	1/1
3	840	355	16	1	A - 201	1/1
4	840	355	16	1	A - 202	1/1
5	806	326	16	1	A - 301	1/1
6	806	326	16	1	A - 302	1/1
7	749	100	16	1	A - 501	1/1
8	749	100	16	1	A - 502	1/1
9	320	100	16	1	A - 503	1/1
10	320	100	16	1	A - 504	1/1
11	140	800	16	1	A - 001	1/1
12	689	399	16	1	A - 002	1/1
13	689	399	16	1	A - 003	1/1
14	856	412	3	2	A - 601	1/1
15	763	302	3	1	A - 602	1/1




**1****3****2****4**


# 5




# 7






# 6



# 8



# 9



# 10

