















Instalation manual

ALEX: Pencil-case




Element symbol	Dimensions				Code	Package
1	1908	354	16	1	A - 105	1/1
2	1908	354	16	1	A - 106	1/1
3	440	355	16	1	A - 203	1/1
4	440	355	16	1	A - 204	1/1
5	406	326	16	1	A - 303	1/1
6	406	326	16	4	A - 304	1/1
7	1269	400	16	1	A - 006	1/1
8	630	400	16	1	A - 007	1/1
9	1926	212	3	2	A - 603	1/1






1**3****2****4**

5



7



6

