










Instalation manual


HO_2S




Element symbol	Dimensions			Code	Package
1	1200	551	1	tabl_2S.001	
2	727	550	1	tabl_2S.002	
3	784	280	1	tabl_2S.003	
4	366	514	1	tabl_2S.004	
5	366	60	1	tabl_2S.005	
6	727	550	1	tabl_2S.006	
7	431	550	1	tabl_2S.007	
8	366	514	1	tabl_2S.008	
9	514	366	1	tabl_2S.009	
10	326	502	2	tabl_2S.010	
11	360	173	2	tabl_2S.011	
12	500	110	2	tabl_2S.012	
13	500	110	2	tabl_2S.013	
14	308	110	2	tabl_2S.014	




1




3







2




4



5**7****6****8**

5



6

