

















ΟΔΗΓΙΕΣ ΑΡΜΟΛΟΓΗΣΗΣ JASMIN ΣΥΝΘΕΣΗ







							ΠΑΚΕΤΟ
1	1700	415	16	1	J-201	1/3	
2	1184	397	16	1	J-202	1/3	
3	518	397	16	1	J-107	1/3	
4	483	396	16	1	J-306	1/3	
5	202	397	16	1	J-111	1/3	
6	1004	415	16	1	J-203	1/3	
7	780	250	16	1	J-305	1/3	
8	300	397	16	1	J-109	1/3	
9	518	413	16	1	J-108	1/3	
10	1368	696	16	1	J-106	2/3	
11	463	1004	16	1	J-101	2/3	
12	270	250	16	1	J-110	2/3	
13	270	250	16	1	J-103	2/3	
14	578	250	16	2	J-302	2/3	
15	312	1197	16	1	J-001	2/3	
16	578	250	16	2	J-307	2/3	
17	636	250	16	1	J-301	2/3	
18	921	250	16	1	J-304	2/3	
19	270	250	16	2	J-102	2/3	
20	200	250	16	2	J-104	2/3	
21	326	1193	3	1	J-601	2/3	




1**3****2****4**


5**7****6****8**




13



15



14



16

